



iMac Intel 24" EMC 2111 RAM Replacement

Upgrade the RAM on your iMac Intel 24" EMC 2111.

Written By: Andrew Bookholt



INTRODUCTION

Use this guide to upgrade the two RAM sticks in your iMac for an instant increase in speed.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)



PARTS:

- [PC2-5300 2 GB RAM Chip](#) (1)
- [PC2-5300 1 GB RAM Chip](#) (1)
- [PC2-5300 512 MB RAM Chip](#) (1)

Step 1 — Access Door




- Loosen the two Phillips screws securing the access door to your iMac.
- ⓘ Both screws remain captive within the access door.
- Remove the access door.

Step 2 — RAM



- Pull both RAM arms away from the iMac to release both RAM chips from their sockets.

Step 3



- Pull both RAM chips out of their slots.
- ★ During reinstallation, make sure both RAM arms are fully rotated outward before inserting the RAM chips. Use your thumbs to seat the new RAM chips into their sockets and then press the RAM arms back into the iMac.
- i It is normal to encounter a fair amount of resistance when pushing the RAM arms back into the iMac.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 11:00:28 AM.